

Version No.: V1.0



Lithium battery protection board

(EK-BM3R10S80A)

Product Datasheet

Shenzhen Enerkey BMS Power Technology Co., Ltd.

Product Name	Lithium battery protection board
Product Model	EK-BM3R10S80A
Version	V1.0
Adapt Battery String	3S/4S/5S/6S/7S/8S/9S/10S
Adapt Battery Type	Li-ion/LiFePO4/Lto/SIB
Function	Overcharge protection, over-discharge protection, over-current protection, over-temperature protection, short-circuit protection
Effective date	28th.Feb.2025

Product change history					
Version	ion Date Change point description A				
V1.0	2025-02-28	Initial version			

Website	www.enerkeybms.com
Mobile No.	+86 15387469240
Address	Area A, 9th Floor, Building G, Guancheng Low Carbon Industrial Park, Shangcun Community, Gongming Street, Guangming District, Shenzhen, China, 518106

Contents

1.	Overview	1
2.	Technical Parameters	1
3.	Product Photo	2
	1) Product Appearance2 2) Accessories3	
4.	Product Drawing	3
5 . l	Product wiring diagram	4
	1). Wiring diagram	
6.	Frequently Asked Questions	8
7. l	Environmental substance requirements	8
8. 9	Safety protection measures, transportation and storage	9
	1) Safety protection measures9	
	2) Packaging and shipping9	
	3) Storage9	



1. Overview

- 1. This series of lithium battery protection boards is a power management system (BMS) tailored for ternary lithium batteries.
- ②. This series of lithium battery protection boards uses automotive-grade MOS, 2oz thickened copper foil and copper strips for current sharing, making the protection board highly precise, with ultra-low internal resistance and ultra-low heat generation.
- ③. On the basis of basic protection board functions such as overcharge protection, over-discharge protection, over-current protection, over-temperature protection, short-circuit protection, etc., a balancing function, reset function, electrostatic protection, dust-proof protection and moisture protection are added.
- ④. This lithium battery protection board (EK-BM3R10S80A) adopts 3S and 4S integrated solutions. You can flexibly select the required number of strings according to the wiring diagram provided by our company.
- ⑤. It is mostly used in the battery packs of electric scooters, electric bicycles, power tools, car washers, small household appliances, model aircraft and other products. Mainly plays the role of protecting the battery pack.


Technical Parameters 2.

		Item type	Parameters							
		Product Model		EK-BM3R10S80A						
		Product Size(mm)				L114*W45*	T12			
		Product Weight(kg)		0.08						
	Parameter	Product Material		FR-4 / Lead-free spray tin						
1	Overview	Applicable battery type	Lifepo	04	Li-	ion	L	to	S	IB
		Applicable battery string			3S/4S	S/5S/6S/7S/8	8S/9S/10S			
		Rated discharge current	80 <i>A</i>	\	80)A	80	0A	80)A
		Peak starting current	160	4	16	0A	16	60A	16	0A
		ltana tuma	Trigger	Trigger	Trigger	Trigger	Trigger	Trigger	Trigger	Trigger
		Item type	(time)	(time)	(time)	(time)	(time)	(time)	(time)	(time)
		Overvoltage protection	3.65V/1S	3.50V/1S	4.25V/1S	4.05V/1S	2.85V/1S	2.75V/1S	3.95V/1S	3.80V/1S
	Charging	voltage value	3.037/13	3.500/15	4.257/15	4.057/15	2.03 V/13	2.737/13	3.337710	3.007/10
2	protection	Overcurrent value	40A/2S, disconnect charger to recover							
	protection	Low temperature value	Charge over-temperature protection 60°C/2S / Release 55°C/2S							
		Overtemperature value	Charging low temperature protection -5°C/2S / Release 0°C/2S							
		Undervoltage protection	2. 30V/1S	2.70V/1S	2. 75V/1S	3. 0V/1S	1. 70V/1S	1.80V/1S	1.50V/1S	2. 00V/1S
		voltage value	2. 30 \$7 13	2. 700/13	2. 754/15	3. 0 v / 13	1. 700/13	1.007/13	1. 30 7 13	2.000/13
		①Overcurrent protection		80	A/2S, disco	nnect load o	or activate c	harging		
		value				Till Cot load C	or activate of	narging		
3	Discharge	②Overcurrent protection	160A/0.5S, disconnect load or activate charging							
	protection	value		100	7 (0.00, aloo	oriireot ioaa	or dollvato	onarging		
		Short circuit protection	260A/128uS, disconnect load or charge activated							
		value		2007	v 12000, alo		a or orial go	donvatou		
		Low temperature value		Discharge o	ver-tempera	ture protect	ion 65℃/2S	, release 60	℃/ 2S	
		Overtemperature value	Discharge low temperature protection -20°C/2S, release -10°C/2S							


	Standby current	25uA
4 Others	consumption	
4 Others	Motherboard lock	
	voltage	1

3. Product Photo

1) Product Appearance



Front Back





Special Note:

1. All products shipped are coated with conformal coating.

2) Accessories

 $\ensuremath{\textcircled{1}}$. NTC Terminal cable



Thermistor terminal cable specifications					
Terminal Specification	Resistance	B value	length	Q'ty	Remark
PH2.0mm_2Pin	10K 1%	B3435	100cm	2	Customizable


2 . Terminal cable



Terminal cable specifications						
Terminal Specification	Material	Number	length	Stripping length	Q'ty	
PH2.54mm_11Pin	Cu	22AWG	40cm	3cm	1	

4. Product Drawing

(No tolerance noted: ±0.15, Unit: mm)



PCB Specifications					
Material	FR-4	Layer	2 layer		
PCB thickness	1.6±0.10	Copper(CU) thickness	2.0 oz		

Pads plating	Lead-free spray tin	Plate thickness	
Solder	Green	Silkscreen	White

5. Product wiring diagram

1). Wiring diagram

EK-BM3R10S80A supports 3-strings, The wiring method is shown in "Figure 5.1.1".




Figure 5.1.1

EK-BM3R10S80A supports 4-strings, The wiring method is shown in "Figure 5.1.2".




Figure 5.1.2

EK-BM3R10S80A supports 5-strings, The wiring method is shown in "Figure 5.1.3".




Figure 5.1.3

EK-BM3R10S80A supports 6-strings, The wiring method is shown in "Figure 5.1.4".




Figure 5.1.4

EK-BM3R10S80A supports 7-strings, The wiring method is shown in "Figure 5.1.5".

Shenzhen Jinwei Power Technology Co., LTD

Figure 5.1.5

EK-BM3R10S80A supports 8-strings, The wiring method is shown in "Figure 5.1.6".




Figure 5.1.6

EK-BM3R10S80A supports 9-strings, The wiring method is shown in "Figure 5.1.7".




Figure 5.1.7

EK-BM3R10S80A supports 10-strings, The wiring method is shown in "Figure 5.1.8".




Figure 5.1.8



3). Precautions for wiring

- ①. Installing the battery protective board requires a certain amount of technical electronic knowledge.
- ②. When wiring, first connect the B- line at the soldering pad position to the total negative terminal of the battery (the B- line should be soldered to a short and thick wire).

And first solder the wired terminals to the battery pack, and then insert the protective plate.

③. The connection between the battery terminal B- and the protection board terminal B- should be short and thick, otherwise it will cause the protection board to charge and discharge in advance and malfunction.

You need to use thick wires when wiring P+/P-. Wires that are too thin and too long will burn the board!

④. After connecting the battery, please pay attention to the insulation protection of the product to avoid short circuit when the power is on;

6. Frequently Asked Questions

Phenomenon	Solution		
After the protective board is installed, No output or wrong output voltage	 Activate the protection board: Connect the charger to power on or short-circuit P- and B- for 2-3 seconds, and then measure whether the output voltage is normal; The wiring order is wrong: measure whether the voltage of each battery string is normal. 		
After the protective board is installed, After using it for a while, the power was cut off.	Check whether the installation position of the NTC probe is normal, It should be installed close to the battery and not placed on the protective board.		

7. Environmental substance requirements

Each battery corresponds to an LED indicator, and you can clearly observe whether each cell is balanced.

Harmful Substance	Limit standard (mg/kg)
Lead (Pb)	1000
Cadmium (Cd)	100
Mercury (Hg)	1000
Hexavalent chromium (Cr6+)	1000
Polybrominated biphenyls (PBB)	1000
Polybrominated diphenyl ethers (PBDE)	1000



8. Safety protection measures, transportation and storage

1) Safety protection measures

- ①. There is no high voltage in the protection board board itself, and it will not cause electric shock damage to the body.
- 2. Do not repair the balancing board while the power is on. All repairs should be performed by qualified service personnel.

If the working voltage set by the factory is changed, the safety certificate no longer applies.

- ③. When using, please pay attention to the insulation treatment of the product to avoid short circuit.
- 4. Pay attention to ESD protection when using this product.
- ⑤. This product complies with the company's thrust standards: 0402 components ≥1.0KgF; 0603 components ≥1.5KgF; IC and MOS tubes ≥2.0KgF.

2) Packaging and shipping

- ①. Separate and package PCBA with anti-static bubble bags.
- 2. The packed products can be transported by ordinary means of transportation when they are not directly affected by rain, snow or violent collisions and bumps.

It is not allowed to be placed together with corrosive substances such as acids and alkalis during transportation.

3) Storage

Packaged products should be stored in a permanent warehouse with a temperature of 0° C ~35 $^{\circ}$ C and a relative humidity of no more than 80%.

The warehouse should be free of acid, alkali and corrosive gases, strong mechanical vibration and impact, and no strong magnetic field.